



transcom

TRANSCENDENCIAS COMERCIALES, S. L.

C.I.F. B-48833404

PRE INSTALLATION INSTRUCTIONS FOR THE MACHINES

- 1.- Install the electric heater with maximum capacity for 70 litres.
- 2.- Put the curb cocks in the hot and cold water pipes.
- 3.- Following the installation of the curb cocks you must install 2 pressure regulators tared at 2 bars., as indicated in the enclosed map.
- 4.- You must put 2 metal flexible tubes of ½", from where you must conect through a pvc tube the enter of the cold and hot water to the machine (see enclosed map).
- 5.- For the evacuation of the machine there must be a PVC point of 32mm diameter with a height no more than 25 centimetres. (see draft)